

1<sup>st</sup> check the machine side receiver light open ( yellow light )



2<sup>nd</sup> turn on the machine



3<sup>rd</sup> press the blue button 1<sup>st</sup> ly



4<sup>th</sup> press blue button then and 1 row right side button town down it



5<sup>th</sup> after done the step 4 press receiver side yellow light side button together longtime



6<sup>th</sup> when it screen show "0" in the middle ,still press



6<sup>th</sup> when it shown some words can release finger , done .

